

Enable BTR-155 Bluetooth RSM on TLK100i

1 Choose WAVE Devices in the WAVE Admin menu and select the device you want to modify. (Click on the TLK100i that you want to modify in the overview)

2 Select Actions.

3 Select Bluetooth Accessories

The screenshot shows the WAVE Admin interface. On the left, a sidebar menu has 'WAVE Devices' circled in orange with a '1' next to it. The main area displays 'Device Info' for a TLK100i device. On the right, an 'Actions' menu is open, with 'Bluetooth Accessories' circled in orange and a '3' next to it. Other menu items include 'Manage WiFi Networks', 'Restart Device', 'Refresh Cellular Status', and 'Radio Wipe'.

	Reported	Desired
Device Type	TLK100i	-
IMEI	354124100009653	-
Serial Number	341AVJ0244	-
Cellular Status	Activated	-

ATTENTION: If Bluetooth is not enabled, you must do this first under Settings and Menu Visibility.

The screenshot shows the Motorola Solutions settings page for a TLK-100 device. The left sidebar has 'TLK 100s' selected. The main area shows various settings, with 'Bluetooth' set to 'On' and its checkbox circled in orange. Other settings include Brightness Level (1), Device Mode (user), Maintenance Mode PW (-), Voice Announcements (On), Location (On), WiFi (On), Cellular (On), Scan (Off), and Do Not Disturb (Off).

Brightness Level	1	1
Device Mode	user	user
Maintenance Mode PW	-	
Voice Announcements	On	<input checked="" type="checkbox"/>
Location	On	<input checked="" type="checkbox"/>
WiFi	On	<input checked="" type="checkbox"/>
Cellular	On	<input checked="" type="checkbox"/>
Bluetooth	On	<input checked="" type="checkbox"/>
Scan	Off	<input type="checkbox"/>
Do Not Disturb	Off	<input type="checkbox"/>

	Reported	Desired
Location	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Alert Tones	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Voice Announcements	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Brightness Level	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Do Not Disturb	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
WiFi	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Cellular	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Bluetooth	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Scan	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Contacts	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

When this is done, you can add Bluetooth accessory:

Up in the right corner, now select Bluetooth Accessories (Step 3)

You need to enter the name Savox BTR-155 and pin code 0000.

Name	MAC Address	Pin Code	Delete	Unpair	Edit
Silentex 3.3.5.2MW	886b0fe5225e	0000	Delete	Unpair	Edit
OCW_EARPIECE_PTT	001b41b24c22	0000	Delete	Unpair	Edit

Save the settings and the RSM can be connected.

The BTR-155 shall be set into LTE mode (Default Mode is LTE mode, pin code 0000)
When powered on the first time, the device goes to pairing mode automatically.

Put the TLK100i in pairing mode by pressing the INFO button repeatedly until you hear Bluetooth searching.

Then all is set and the BTR-155 RSM works.